




CODO SO		
(C-CODOSO3/8)	CODO 3/8	\$
(C-COD3/8SOHI)	CODO 3/8 SO/HI	\$
(C-COD3/8*1/2SO/HI)	CODO 3/8*1/2SO/HI	\$
(C-COD3/8*1/2SO/HE)	CODO 3/8SO*1/2HE	\$
(C-CODOSO1/2)	CODO 1/2 SO	\$
(C-CODOSO3/4)	CODO 3/4 SO	\$
(C-CODOSO3/4*1)	CODO 3/4*1 SO	\$




CODO SO/1/2HE	CODO SO/1/2HI	
(C-CODOSOHE1/2)	CODO SO HE 1/2	\$
(C-CODOSOH1/2)	CODO SO HI 1/2	\$
(C-CODOSOHE1)	CODO SO HE 1/2	\$



TEE		
(C-TEESO1/2)	TEE SOSO1/2	\$
(C-TEESO3/8)	TEE SOSO3/8	\$
(C-TEESO1)	TEE SO1	\$
(C-TEESO3/4*1/2*1/2)	TEESO3/4*1/2*1/2	\$
(C-TEESOH1/2)	TEESO3/4*1/2*1/2	\$



TERMINAL SO/HE		
(C-TERMSOHE)	TERMINAL SO/HE 1/2	\$
(C-TER1/2HE*3/8SO)	TER1/2HE*3/8SO/HE 1/2	\$
(C-TER3/4*1/2)	TERMINAL SO/HE3/4* 1/2	\$



TERMINAL SO/HI		
(C-TERMSOHI)	TERMINAL SO/HI 1/2	\$

