

TARUGO CLAVO	\$ %
---------------------	-------------

(*TARCLAV6*60) (*TARCLAV8*60) (*TARCLAV8*80) (*TARCLAV8*100)		TARUGO CLAVO 6*060 8*060 8*080 8*100	
---	---	--	--

HILO X METRO	\$ C/U
---------------------	---------------

(*HMTR1/4) (*HMTR5/16) (*HMTR3/8) (*HMTR1/2) (*HMTR5/8) (*HMTR3/4) (*HMTR7/8)	HILO POR MTR 1/4 HILO POR MTR 5/16 HILO POR MTR 3/8 HILO POR MTR 1/2 HILO POR MTR 5/8 HILO POR MTR 3/4 HILO POR MTR 7/8	
---	---	--